




# Review

Suresh Devasahayam  
Department of Bioengineering  
Christian Medical College, Vellore

# Ultrasound Measurement

# Ultrasound Reflection Measurement



# Ultrasound Instruments

- Time of echo:

$$\tau = 2 \frac{d}{c}$$


- Attenuation:

$$\frac{I_r}{I_o} = e^{-\mu(2d)}$$

- Automatic depth dependent gain compensation

# Flow measurement

- Transit time =  
distance / (effective velocity in medium)




# Doppler shift

- Source frequency  $f_o$
- Source-target velocity  $u$
- Propagation in medium with velocity  $c$
- Dopplet shift  $f_d$

$$\frac{f_d}{f_o} = \frac{u}{c}$$

# Flow Measurement

# Dilution methods




$$C_i F + \frac{dm}{dt} = C_o F$$

$$F = \frac{dm/dt}{C_o - C_i}$$




# Digital Measurement

# Digital Temperature sensor - TMP100




# Digitization and Quantization




# Inertial Sensors

# Measurement of Acceleration



# Gyroscope Principle



## Disc gyroscope

$$mgr = \omega_s \omega_p I_s$$

- Mass,  $m$
- Radius of disc,  $r$
- Spin angular vel
- Precession angular vel
- Spin moment of inertia

## Vibrating gyroscope – Coriolis force

- Force,  $F$
- Angular Velocity of rotation/precession
- Linear velocity of oscillation
- Mass,  $m$

$$F = -2 \omega_p v_{osc} m$$




# Distance Measurement

# Triangulation calculation

$$\frac{d}{h} = \frac{x_o}{x_1}$$

$$d = x_o h \cdot \frac{1}{x_1}$$




# ToF LiDAR

## System block diagram



Figure 1. VL53L0X block diagram



# Radiation Thermometry

# Stefan-Boltzman Law – radiation (absorbed/emitted)

- Integrating Wien's equation can get total thermal power
  - integrate numerically
- Empirical formula by Stefan and Boltzman
- For black body, the emissivity is 1
- 'A' is a geometry factor


$$P_{tot} = A \epsilon \sigma T^4$$

$$P_{tot(blackbody)} = \sigma T^4$$

$$\sigma = 5.67037 \text{ Wm}^{-2} \text{ K}^{-4}$$

# Biopotential Electrodes


# Measurement model



# Photospectrometry



# Absorption spectrum change of phenol red with pH



## Examples requiring Design

# 1. Measuring eye-blink for noise removal

- Noise in EEG recording
- Remove noise by subtracting blink event-related potential
- Determine transfer relation between blink measurement and EEG measurement

## 2. Measuring eye-blink to use as control signal

- Locked-in patients – eye-blink under voluntary control
- Encode intention as sequence of eye-blinks

### 3. Electrogastrography

- Measure peristalsis
- Distinguish signal from movement noise

## 4. Measuring Blood flow in tissue

- Photoplethysmography
- Impedance plethysmography

## 5. Separating signal from noise

- Similar characteristics
  - ECG/EMG
  - EEG/EMG
- Different characteristics
  - ECG/respiration
  -

# Designing Measurement Systems

- Sensitivity
- Selectivity
  - Noise immunity
- Linearity
- Dynamic response
- Non-invasive
  
- Portability
  - Battery operation
  - Wireless data transfer