

Resistive Displacement & Force Sensors Strain Gauges

Suresh Devasahayam
Department of Bioengineering
Christian Medical College, Vellore

Lecture - Outline

- Strain gauges
 - Load cells
 - Force measurement
 - Pressure measurement
- Thermistors
 - Temperature measurement
 - Self-heating

Strain Gauge

- Resistance
- Taking log
- Differentiating
- Fractional change of resistance
- Can calculate for a cylinder, $A=\pi r^2$
- Poisson's ratio σ is 0.5 for incompressible solids (constant volume), 0.3 for metals

$$R = \rho \frac{l}{A}$$

$$\ln R = \ln \rho + \ln l - \ln A$$

$$\frac{d \ln R}{dR} = \frac{1}{R}, \text{ Thus : } d \ln R = \frac{dR}{R}$$

$$\frac{dR}{R} = \frac{d\rho}{\rho} + \frac{dl}{l} - \frac{dA}{A}$$

$$\frac{\Delta R}{R} = \frac{\Delta l}{l} - \frac{\Delta A}{A} + \frac{\Delta \rho}{\rho}$$

$$\frac{\Delta r}{r} = -\sigma \frac{\Delta l}{l} \quad \frac{\Delta A}{A} \approx 2 \frac{\Delta r}{r}$$

$$\frac{\Delta R}{R} = \frac{\Delta l}{l} + 2\sigma \frac{\Delta l}{l} + \frac{\Delta \rho}{\rho}$$

Strain Gauge (contd)

- Temperature dependence of resistivity
- Temperature dependence of length
-

$$\rho = \rho_o [1 + \alpha_R (T - T_o)] = \rho_o + \Delta \rho_T$$

$$l = l_o [1 + \alpha_l (T - T_o)]$$


$$\frac{\Delta R}{R} = \frac{\Delta l}{l} (1 + 2\sigma) + \frac{\Delta \rho_T}{\rho} = G \frac{\Delta l}{l} + \alpha_R \Delta T$$

Strain Gauge Examples

Material	Temperature Coeff α_E	Maximum strain $\Delta l/l$	Modulus of Elasticity Y	Gauge factor G
Platinum	0.0038	0.0023	1.5×10^{10}	6
Nichrome	0.0004	0.0036	19×10^{10}	2.5
Silicon	0.007	0.0033	19×10^{10}	170

Load Cell

Load Cell – cantilever beam



Bending of the cantilever beam

- Deflection of beam

$$\delta = \frac{W l^3}{3 Y I_{xx}} \quad \text{where} \quad I_{xx} = \frac{1}{12} b h^3$$

- Horizontal distance:

$$l^2 - \delta^2 = r^2 - (r - \delta)^2$$

- Similar Sectors:

$$\frac{\Delta l}{l} = \frac{h/2}{r}$$

- Substituting for r:

$$\frac{\Delta l}{l} = \frac{h \delta}{l^2}$$

- Strain in surface fibres:


$$\frac{\Delta l}{l} = \frac{h \delta}{l^2} = \frac{4 W}{Y b h^2}$$

Mechanical Equivalent

$$F(t) = K x(t) + B \frac{dx(t)}{dt} + M \frac{d^2 x(t)}{dt^2}$$


$$X(s) = \frac{F(s)}{K + Bs + Ms^2}$$

$$X_o(s) = \frac{A F(s)}{\frac{s^2}{\omega_n^2} + 2 \frac{\zeta}{\omega_n} s + 1}$$



Pressure Transducer

Pressure Measurement



Equivalent of catheter fluid system


$$L_c = \frac{\rho l}{A}$$

$$C_c = \frac{Ald}{Eh}$$

$$R_c = \frac{8\pi\eta l}{A^2}$$


$$C_d = \frac{1}{E_d}$$

$$C_b = \frac{\Delta V_b}{\Delta P_b}$$



Thermistors – negative temperature coefficient sensors

Thermistors



Thermistors

- Thermistor characteristics

$$R_T = R_o e^{\beta(\frac{1}{T} - \frac{1}{T_o})}$$

- Sensitivity:

$$\ln R_T - \ln R_o = \frac{\beta}{T} - \frac{\beta}{T_o}$$


$$\frac{1}{R_T} \frac{dR_T}{dT} - 0 = \beta \frac{-1}{T^2} - 0$$

$$\frac{1}{R_T} \frac{dR_T}{dT} = \frac{-\beta}{T^2}$$

- Non-linear sensitivity:

$$\frac{\Delta R_T}{R_T} = \Delta T \left(\frac{-\beta}{T^2} \right)$$

Voltage-Current characteristics



Thermistor self-heating

- Power dissipation (due to electric current) results in heating of thermistor
- As temperature changes, resistance decreases
- Equilibrium is reached when the electrical power is equal to the thermal power dissipated

$$P = CM \frac{dT}{dt} + D(T - T_a)$$

where C = sp. heat, M = mass, D = dissipation constant

$$T = T_a + \frac{P}{D} \left[1 - e^{-\frac{D}{CM}t} \right]$$

steady state : $D = \frac{P}{T - T_a}$

Application of Thermistor in Self-Heating

- Measurement of fluid flow – changing dissipation constant
- Mass flow meters
 - gas and liquid flow sensors