Transducers & Instrumentation

Module 01/02

(Sensor Dynamics Characteristics; LTI system; Convolution; Laplace Transform; Frequency Response; Zero, First, and Second Order LTI systems)

Sensor dynamic characterization

Many sensors do not respond instantaneously to a given input.


E.g., Contact thermometer

 Mathematically described using differential equations relating the measured and other inputs to the sensor output.

 A common and very useful model for such dynamical systems are linear time invariant systems.

Linear Time Invariant Systems

Both Linear and Time Invariant.



Some useful signals

• Step signal:
$$1(t) = \begin{cases} 1 & t \ge 0 \\ 0 & t < 0 \end{cases}$$

- Exponential signal: $A \cdot e^{\beta t}$
- Sinusoidal signals: $A \cdot \sin(\omega t + \varphi)$

Some useful signals

• Dirac Delta Function
$$\delta(t)$$
:
$$\int_a^b \delta(t) dt = \begin{cases} 1, & 0 \in [a, b] \\ 0, & 0 \notin [a, b] \end{cases}$$

$$\int_{a}^{b} f(t)\delta(t - t_0)dt = \begin{cases} f(t_0), & t_0 \in [a, b] \\ 0, & t_0 \notin [a, b] \end{cases}$$

Input-Output Relationship of LTI systems



Convolution



Impulse Response



Another Description of LTI systems



$$a_n \frac{d^n y}{dt^n} + a_{n-1} \frac{d^{n-1} y}{dt^{n-1}} + \dots + a_1 \frac{dy}{dt} + a_0 y = b_m \frac{d^m x}{dt^m} + b_{m-1} \frac{d^{m-1} x}{dt^{m-1}} + \dots + b_0 x$$

Laplace Transform

- A very popular and useful integral transform method for analysing LTI systems.
- Unilateral Laplace transform.

$$X(s) \triangleq \int_{0^{-}} x(t)e^{-st}dt$$
, $s \in \mathbb{C}, s = \sigma + j\omega$

• Laplace Transform Pairs:

$$x(t) \stackrel{\mathcal{L}}{\longleftrightarrow} X(s)$$

Laplace Transform Pairs

Time Domain Signal	Laplace Transform
1(<i>t</i>)	
$e^{at}1(t)$	
$\sin(\omega_0 t) 1(t)$	
$\delta(t)$	

Laplace Transform Property

• x(t) and X(s) are Laplace transform pairs. Then,


$$y(t) \stackrel{\mathcal{L}}{\longleftrightarrow} Y(s) \Longrightarrow ax(t) + by(t) \stackrel{\mathcal{L}}{\longleftrightarrow} aX(s) + bY(s)$$

$$x(t) \stackrel{\mathcal{L}}{\longleftrightarrow} X(s) \Longrightarrow \frac{dx}{dt} \stackrel{\mathcal{L}}{\longleftrightarrow} sX(s) - x(0^{-})$$

Why is the Laplace Transform useful for LTI systems?




Transfer Function of an LTI system



$$Y(s) = H(s)X(s) \Longrightarrow H(s) = \frac{Y(s)}{X(s)}$$


Frequency Response of an LTI System



$$H(j\omega) = H(s)\Big|_{s=j\omega} = \frac{Y(j\omega)}{X(j\omega)}$$

$$H(j\omega) = |H(j\omega)|e^{j\arg(H(j\omega))} \to \begin{cases} |H(j\omega)| & \text{Magnitude Response} \\ \arg(H(j\omega)) & \text{Phase Response} \end{cases}$$

Zero Order System




Pure Linear Resistor Pure Linear Spring

$$x(t) \longrightarrow LTI \text{ System} \longrightarrow y(t)$$


$$a_1 \frac{dy}{dt} + a_0 y = b_0 x$$


Time Constant:
$$\tau \triangleq \frac{a_1}{a_0}$$

Static Sensitivity:
$$K \triangleq \frac{b_0}{a_0}$$



RC / RL circuits
Spring-damper/Mass-damper





Second Order System

$$x(t) \longrightarrow LTI \text{ System} \longrightarrow y(t)$$


$$a_2 \frac{d^2y}{dt^2} + a_1 \frac{dy}{dt} + a_0 y = b_0 x$$

$$K \triangleq \frac{b_0}{a_0}$$

$$\omega_n \triangleq \sqrt{\frac{a_0}{a_2}} \implies \frac{1}{\omega_n^2} \frac{d^2y}{dt^2} + \frac{2\zeta}{\omega_n^2} \frac{dy}{dt} + y = Kx$$


$$\zeta \triangleq \frac{a_1}{2\sqrt{a_0 a_2}}$$

Second Order System




RLC circuits
Mass-Spring-damper

Second Order System Response




Second Order System – Frequency Response



Dynamic characterization of sensors

• Identifying sensor parameters from measured data.



- System identification tools can be used for doing this.
- Simple procedure for first order system using a step response.

$$y(t) = K \cdot \left(1 - e^{-t/\tau}\right) \Longrightarrow \log_e \left(1 - \frac{y(t)}{K \cdot x(t)}\right) = -\frac{t}{\tau}$$

Dynamic characterization of sensors

